



CINI

INSTALLATION

USE

- Entrust the heater installation to a qualified person.
- The QSX heating element is designed so as to be installed independently from the thermostat
- The heater is designed only for direct installation into the radiators or towel dryers.
- The heating element is installed in the 1/2" hole on the heater body bottom.
- Remove the screw from the bottom side of the radiator and screw the QSX heating element. Use the standard wrench No. 22 for installation.
- The QSX heating element is the immersion type, which requires installation only at the bottom of the radiator (installing the heater on top of the heating body may lead to accidents and damages)
- The heating element has gaskets that provide a proper seal to the heating body and to the thermostat so that additional parts and materials for the same purpose are not to be used.
- After properly installed heating element, approach to filling in the radiator with fluid.
- Allowed fluid for proper functioning is demineralized water (H2O).
- Other fluids used for filling in the central heating system are also allowed.
- Fill in the heating body to 90% volume, bigger fluid quantity than required may cause damage to the heating body.
- Once you fill the radiator with fluid, you may install the thermostat, rotate to the desired visual zone and fix with the screw on the back of the heater.
- If you are sure whether you installed the heater and thermostat in accordance with previous instructions, you can connect the thermostat to the power network, in the socket with grounding.
- Cable cross-section in the installation and the type of connection must be appropriate.
- Immediately after the connection to the power network, the thermostat indicators will turn on and off in an easily discernible sequence, and the indicator marked with a snowflake, the temperature indicator and the heater operation indicator (3) will remain turned on.
- If after 10 seconds after turning on the heater to an electrical installation all indicators flash in the same regime, there has been an error while installing the thermostat on the heating element. Turn off the thermostat from the electrical wiring, loosen the screw on the back of the thermostat, remove the thermostat from the heater and carefully repeat the thermostat installation procedure.
- QSX Heater is equipped with a mask which hides cable connection to the electric power supply.
- Thermostat equipped with power on/off switch on its housing.

WARNING

- The heater is designated exclusively for direct installation on radiators or towel dryers. heater power must not exceed 70% of the power in the heating body that incorporates the heater. it is prohibited to connect the electric heater to power supply if it is not completely submerged in water. it is prohibited to install the heater in heating bodies that are filled with aggressive fluids.
- Thermostat housing must not be covered and it must be at least 400mm away from flammable objects and materials.
- connection to the electrical installation must be performed only in the manner prescribed by the manufacturer
- allow cable replacement, servicing and installation to qualified persons only
- if you want to place the thermostat completely out of operation, disconnect the cable from the electrical installation
- if there is mechanical damage, disconnect the cable from the power supply and contact the authorized technician
- the device must not be handled by children and people of limited mental and physical abilities
- the appliance is not intended for fun and entertainment

If you are sure that you have installed all the elements in accordance with these instructions, you may plug the cable into the socket with protective grounding. Installation cable cross-section and the type of connection must be appropriate.

Please set the power switch in position 1.

After the self-test, the indicator will illuminate.

You may choose the wanted temperature range in accordance with the next procedure:

User interface

- testing program - self test after connecting to the network all led lights will light up at the preset sequence with the aim of checking all functions as well as the presence of required elements.
- After the self test, if operating conditions are met, the thermostat will activate the (5°C) and the indicator (4).

If all led lights are flashing simultaneously, there is a problem with the temperature sensor function. It is necessary to check the connection between the heating element and the thermostat.

- Key controls (5, 6)

By pressing the marked key, you will activate the following functions:

- ON: press and hold key (5) by 4 s to turn ON the QSX
- OFF: if the QSX is in the ON state and/or TIME mode press and hold key (5) for 4 s to turn OFF the QSX.

By pressing the same key for 1 s, the preset temperature will change in cycles ranging from 5°C to 65°C

- by pressing the key (6) for 3 s the heating period will be activated in fixed duration of 2 hours at the preselected temperature
- Heater function indicator - illuminated line at the bottom of the thermostat housing (3)
- Displaying the temperature with elliptical indicator (4)

Indication levels

- blue temperature up to 20°C
- green radiator temperature 40°C, 50 °C
- red temperature from 55°C, 65°C.
- flashing red light radiator temperature exceeds 65 degrees, possible radiator overheating

Displaying the temperature is independent of the heating manner, heating element or the central heating system.

- Temperature ranges
- 5°C freezing protection. The thermostat will start this mode after the self test every time there is network power shortage.
- 40°C, 50°C temperature ranges recommended for heating and drying.
- 65°C, 55°C temperature ranges recommended for heating only.

4.2.4.6 Time settings - sensor

Possibility of selecting the heating period in duration of 2 h at a preset temperature.

If this mode is active the indicator light will flash slowly during the first hour and faster during the second hour of heating.

After the expiration of 2 hours, the thermostat will exceed the range marked (5) stops the heating and continues to maintain the minimum temperature)

If there is a need to terminate the preset time period, switch off the heater and start again with the ON / OFF function according to the previously described ON/OFF procedure




IMMERSIBLE HEATER WITH ELECTRONIC THERMOSTAT TYPE QSX

USERS GUIDE

CINI Sp. z o.o.
Ul. Borowa 85
41 253 Czeladź Polska
Tel: + 48 32 265 65 33
Fax: + 48 32 265 30 37
e-mail: cini@cini.com.pl
www.cini.com.pl

CINI






www.cini.com.pl


CINI

www.cini.com.pl

- ① — QSX 150 QSX 300 QSX 600 QSX 900
- ② — 5-65 C +/- 3 [°C]
- ③ — H05VV-F 3G0.75
- ④ — 230V~50Hz
- ⑤ — 2 [h]
- ⑥ — 1000 [W]
- ⑦ — IP65
- ⑧ — I
- ⑨ — 102 [°C]
- ⑩ — G1/2"
- ⑪ — 150+5/-10% 300+5/-10% 600+5/-10% 900+5/-10% [W]
- ⑫ — 373+/-5 385+/-5 402+/-5 416+/-5 [g]
- ⑬ — 252+/-5 294+/-5 344+/-5 394+/-5 [mm]



④



⑤

IMMERSIBLE HEATER WITH ELECTRONIC THERMOSTAT TYPE QSX

USER GUIDE

Heater with electronic thermostat type QSX is a device used exclusively for heating fluids in heating appliances, such as radiators and towel dryers, which are installed as a stand-alone heating elements, or as part of the central heating system.

NOTE

For proper and optimal performance, as well as the optimal heating effects, the right choice of the heating appliance and the heater is very important

Installation of devices and choice of the heating appliance should be entrusted to a qualified person

TECHNICAL DATA

QSX HEATING ELEMENT

Basic parts of the QSX heating element:

1. Tubular immersion heater
2. Tube with temperature sensor
3. Flange on which all QSX parts are mounted
4. Parts for connection to the power supply
 - Elements for temperature signal transmission
 - Rotating connector element that provides a connection to the thermostat housing
 - Seals
 - Built-in thermal fuse

- ① — model
- ② — temperature regulation
- ③ — connection cable
- ④ — connection voltage
- ⑤ — timer
- ⑥ — MAX allowed heater power
- ⑦ — protection class
- ⑧ — Insulation class
- ⑨ — built-in thermal fuse
- ⑩ — mechanical connection
- ⑪ — heater power
- ⑫ — QSX weight
- ⑬ — lenght

QSX THERMOSTAT

③ - vertical mounting

④ - schematic diagram

I. General characteristics

- Power switch - provides disconnection from the electrical network
- Modern key-control user interface
- Simple adjustment by pressing the marked key on the thermostat
- Increased levels of sealing, reduced the possibility of moisture penetration
- Intelligent Control System

II. Basic elements of the QSX thermostat

1. thermostat housing
2. temperature range indicators
3. heater indicator
4. temperature level indicator
5. range/function selection switch ON-OFF
6. timer
7. swivel joint
8. fixing screw
9. Inlet
10. power switch
11. connection cable
12. Dimensions (HxWxL): 91x60x51mm
13. Sliding mask